SENSING

"ID" TANK

**PRESSURE
TO CLOSE
SPRING TO
OPEN**

SUPPLY

=

OUTPUT

EXHAUST

P2

P1

SENSING

"ID" TANK

PRESSURE TO CLOSE SPRING TO OPEN

SUPPLY

OUTPUT

EXHAUST

P2

P1

SENSING

"ID" TANK

PRESSURE TO CLOSE SPRING TO OPEN

SUPPLY

OUTPUT

EXHAUST

P2

P1

SENSING

"ID" TANK

PRESSURE TO CLOSE SPRING TO OPEN

SUPPLY

OUTPUT

EXHAUST

P2

P1

SENSING

"ID" TANK

PRESSURE TO CLOSE SPRING TO OPEN

SUPPLY

OUTPUT

EXHAUST

P2

P1

SENSING

"ID" TANK

PRESSURE
TO CLOSE
SPRING TO
OPEN

SUPPLY

OUTPUT

EXHAUST

P2

P1

SENSING

"ID" TANK

**PRESSURE
TO CLOSE
SPRING TO
OPEN**

SUPPLY

OUTPUT

EXHAUST

P2

P1

=